




## Stop, Strainer and Check Valve

- S60-003 — Brass Valve Only
- S60-003A — Plated Valve Only
- S60-003S — Brass Valve with Tailpieces, Nuts and Washers
- S60-003AS — Plated Valve with Tailpieces, Nuts and Washers


Above include S21-014 Celcon plastic stop assembly.



**Parts List** S60-003 Stop, Strainer and Check Valve


Item	Part No.	Qty	Description
1	118-039	1	Valve Body - Brass
1	118-039A	1	Valve Body - Plated
2	160-131	1	Set Screw
3	S21-014	1	Stop Assembly - Celcon
3	S21-026	1	Stop Assembly - Brass
*4	156-006	1	Strainer
*5	124-001BV	2	Fiber Washer
*6	153-068	2	Plug - Brass
7	129-007	1	Tail Piece - Brass
7	129-007A	1	Tail Piece - Plated
8	110-005	1	Tail Piece Nut - Brass
8	110-005A	1	Tail Piece Nut - Plated
*9	124-001AF	1	Tail Piece Washer
*10	135-001AB	1	Spring
*11	S21-015	1	Check Assembly

\* S45-050 Repair Kit Includes these parts




**Parts List** Stop Assembly S21-014  
Standard Celcon Core

Item	Part No.	Qty	Description
1	119-057	1	Valve Core
*2	125-001AW	1	"O" Ring
*3	125-001L	1	Bibb Washer
4	160-164	1	Screw



**Parts List** Stop Assembly S21-026  
Optional Brass Core

Item	Part No.	Qty	Description
1	119-038	1	Valve Core
*2	125-001AW	1	"O" Ring
*3	125-001L	1	Bibb Washer
4	160-146	1	Screw



**Parts List** Check Assembly S21-015\*

Item	Part No.	Qty	Description
1	119-091	1	Plunger
2	125-001BB	1	Washer