


Warning: When servicing or replacing components, make certain that the water supply is turned OFF and the push button tripped to relieve pressure in the vessel.

Flushmate® 501-A Series



List of Components for 501-A Series

- | | |
|---------------------------------------|--|
| 1. Lower Supply Group w/Hose BL100504 | 4. Flush valve cartridge assembly C-100500 |
| 2. Upper Supply Group BU100505 | 5. Vessel |
| (D) Air Inducer | 6. Discharge extension w/drain |
| (E) Vacuum Breaker | |
| 3. Name plate w/Serial Number | |

If you see the part or parts you believe you would like, please indicate the part numbers with the prefix WCI, on your email order form.



[Click here to e-mail our technicians with your problem](#)

[Click here to place your order](#)