


To order items on this page — full catalog number requires prefix

Halsey Taylor.

PUSH BUTTON STEM ASSEMBLIES


PUSH BUTTON ASSEMBLY – 60-06429-51-590

REF NO	PART NUMBER	DESCRIPTION
1	16-06199-08-550	Adjusting Collar
2	11-10695-42-590	Set Screw
3	11-07459-43-550	Speed Clip (2 each)
4	10-08137-31-870	Snap In Bushing




PUSH BUTTON ASSEMBLY – 60-07553-51-590

REF NO	PART NUMBER	DESCRIPTION
1	16-06199-08-550	Adjusting Collar
2	11-10695-42-590	Set Screw
3	11-07459-43-550	Speed Clip (2 each)
4	10-08137-31-870	Snap In Bushing




PUSH BUTTON ASSEMBLY – 60-10337-51-590

REF NO	PART NUMBER	DESCRIPTION
1	16-06199-08-550	Adjusting Collar
2	10-08137-31-870	Snap In Bushing
3	11-10695-42-590	Set Screw



PUSH BUTTON ASSEMBLY – 60-14511-51-590

REF NO	PART NUMBER	DESCRIPTION
NO PARTS AVAILABLE		



PUSH BUTTON ASSEMBLY – 60-14743-51-590

REF NO	PART NUMBER	DESCRIPTION
1	16-06199-08-550	Adjusting Collar
2	11-10695-42-590	Set Screw
3	11-07459-43-550	Speed Clip (2 each)
4	10-08137-31-870	Snap In Bushing

